





Changing the Commander NT & BCM Time and Date



Set Time and Date:

Programming Overlay:

When you begin programming, a group of keys on the keystation become the keys for moving through programming headings and settings. The programming overlay is a paper cutout that shows what the four keys do during programming.


Placing the programming overlay:



1. 
2. * * 2 6 6 3 4 4
3. 2 3 6 4 6
4. Press  five times

Feature	
Password	RETRY
Time & Date	

This facsimile transmission contains confidential information intended only for the use of the person named above. Unauthorised use of this information is prohibited. If you have received this transmission by mistake, please notify the sender immediately.

5. Press
6. Press dial key pad to enter the hour
7. This will display if you have entered numbers less than 12
4. Press
5. Press
6. Press dial keys to enter minutes
8. Press
9. Press
10. Press dial keys to enter year
11. Press
12. Press
13. Press dial keys to enter month
14. Press
15. Press
16. Press dial keys to enter day
17. Press  to end your session

Hour: 01 NEXT	CHANGE
Hour: __ CANCL	
AM OK	CHANGE
Hour: 13 NEXT	CHANGE
Minutes: 00 NEXT	CHANGE
Minutes: CANCL	
Minutes: 30 NEXT	CHANGE
Year: 99 NEXT	CHANGE
YEAR: __ CANCL	
Months: 01 NEXT	CHANGE
Months: __ CANCL	
Months: __ CANCL	
DAY: 01 NEXT	CHANGE
DAY: __ CANCL	
Day: 15 NEXT	CHANGE
End of session	