



Changing the Samsung OfficeServ 700 Time and Date

> From any Display handset follow these instructions with the handset down.

1. Press TRSF key

2. Dial 200

3. Dial 1234

4. Dial 1

5. Press SPEAKER key

6. Dial 505

7. Enter new day date and time in format shown on display

> W: Weekday (1 for Monday to 7 for Sunday)

> MM: Month of year (01 to 12)

> DD: Day (01 to 31)

> YY: Last 2 digits of year

> HH: Hour (24 hr clock - 00 to 23)

> MM: Minutes (00 to 59)

8. Press TRSF key